

407 – 15216 North Bluff Road White Rock, BC Canada V4B 0A7 Phone: 604.424.9092 Toll Free: 1.877.352.9158 Fax: 1.877.453.0658 Email: info@microedgeinstruments.com Web: www.microedgeinstruments.com



Please skip this document if your operating system is NOT Windows 8!

For Windows 8 user, in order to install USB Driver properly, the following steps must be followed before the installation of SiteView software:

1. Restart PC for Advanced Options

A. Mouse over the lower-right corner of the screen and select Settings.



B. Select Change PC Settings.



C. For Windows 8.0:

Navigate to General and under Advanced Startup. Click Restart Now.

PC settings				
r e settings	Language			
Personalize	Add or change input methods, keyboard layouts, and languages. Language preferences			
Users	Refresh your PC without affecting your files			
Notifications	If your PC isn't running well, you can refresh it without losing your photos, music, videos, and other personal files.			
Search	Get started			
Share				
Canada	Remove everything and reinstall Windows			
General	If you want to recycle your PC or start over completely, you can reset it to its factory			
Privacy	Get started			
Devices				
140 1	Advanced startup			
Wireless	Start up from a device or disc (such as a USB drive or DVD), change Windows			
Ease of Access	startup settings, or restore Windows from a system image. This will restart your PC. Restart now			
C				

For Windows 8.1: Navigate to **Update and recovery** > **Recovery**, click **Restart Now**.

	PC settings	Q
	PC and devices	
	Accounts	
	OneDrive	
	Search and apps	
	Privacy	
	Network	
	Time and language	
	Ease of Access	
\langle	Update and recovery	



2. Change Advanced Options

D. Now Windows 8 will restart in the advanced menu options, click on Troubleshoot.

Choo	ose an option
\rightarrow	Continue Exit and continue to Windows 8
11	Troubleshoot Refresh or reset your PC, or use advanced tools
Ċ	Turn off your PC

E. Click on Advanced options.



F. Click the **Startup Settings** option from the menu.

E	Adva	Advanced options				
		System Restore Use a restore point recorded on your PC to restore Windows	C:\	Command Prompt Use the Command Prompt for advanced troubleshooting		
	.	System Image Recovery Recover Windows using a specific system image file	₿	Startup Settings Change Windows startup behavior		
	< \$ >	Automatic Repair Fix problems that keep Windows from loading				

G. The Startup Settings will allow you to change various Windows configuration options. Click **Restart**.



H. Now Windows 8 will reboot. But instead of going to the Desktop it will start in the Startup Settings page. Choose option: 7) **Disable driver signature enforcement** by pressing F7 or the number 7. Then the windows will boot to the mode allowing the USB Driver to be installed properly.

Startup Settings	
Press a number to choose from the options below:	
Use number keys or functions keys F1-F9.	
1) Enable debugging	
2) Enable boot logging	
3) Enable low-resolution video	
4) Enable Safe Mode	
5) Enable Safe Mode with Networking	
6) Enable Safe Mode with Command Prompt	
(7) Disable driver signature enforcement	
8) Disable early launch anti malware protection	
9) Disable automatic restart after failure	
Press F10 for more options	
Press Enter to return to your operating system	

Windows 8 is now ready for SiteView installation.